


Engine Backplate

18




The engine backplate should be the final piece of the model assembly.
Fit the trough notches first, then align the outer edges.
Some final trimming may be required after this part has been attached.

Inner Engine Form

(Place this inside the engine section 4 Cm [if model printed at full size] from the rearmost edge)

17



This part is placed inside the engines at the angle junction of the engine parts.
A central point is provided for internal structural support beam (or dowel), if desired.